

Mobile music box



ON /OFF
button

Volume buttons
Long press

Modus
let's the mobile
rotate with or
without music

Next song
Short press

2X AA batteries

More than 15 songs
playing non stop
for 15 min.

MUSIC BOX WOODLOOK



9

502758

831561

Little Loya



Baby mobiles

Mobile music box

ON /OFF
button

Volume buttons
Long press

Modus
let's the mobile
rotate with or
without music

Next song
Short press

2X AA batteries

More than 15 songs
playing non stop
for 15 min.

MUSIC BOX WHITE



9

501636

149695

Little Loya



Baby mobiles